WG BHZ CONSOLE | 1/83 by KFGCU





Cont. 5-7
around dinner.

Solvang


L-4B
H.V.
RF
o/p
i/p
VOX
RELAY
HV/PWR
SUPPLY
(bundle)
SM220
RF i/p
GRY COAX
SM220
DRIVE o/p
BLK COAX
(large)
TS-830S
BRN pair
WATTMETER
SENSOR
LOAD
i/p
WATTMETER
GRY
(Bundle)
ANTENNA
SWITCH
GRY RG8
SM220
RF o/p
RG213 BLK
PC-1
LINE
SPKR
RX IN
NULL/
MONI
mic
PHONE
LINE
WAT
SP230
A i/p
BLK (shielded)
TS-830S
MIC
CONNECTOR
BLK
TS830S
EXT. SPKR
R/W, BLU/W
(twisted pair)
PC-1
mic
DESK MIC
BLK
OR
TO RTTY SW
SP-230
INPUT
A
B
LINE
OUT
N.C.
N.C.
PC-1
SPKR o/p
BLK (shielded)
ANTENNA SELECTOR
40
20/15/10
80
Dummy
N.C.
N.C.
40m
DIPOLE
BLK
80m
DIPOLE
BLK
WATTMETER
SENSOR
GRY RG8
DUMMY
LOAD
BLK
THGDXX
BLK


TTY LOOP
twisted pair
R/W, BLU/W
SCOPE SW
RTTY
GRY (shielded)
Shield
ST-5000
AC 3 cond BLK
to
TTY
LOOP-
LOOP+
GND
STDBY
CW IO
FSK
SPACE
GND
MARK
AUDIO
OUT
GND
IN
red
clear
RTTY SW
GRY
AC 2 COND
BLK zip
3 wires
R/W, R/W
BLU/W to GND
N.C.
SM220
HORZ. i/P
BLK COAX


RTTY
SW.
PC-1 mic
GRY
HAL
AUDIO
GRY
TR9000
mic
GRY
9000
8305
3PDT
PC1 GND
TR 9000 GND
TTY/HAL GND

	WG6BHZ CONSOLE	1/83 by KF6CU

TS-830S

SM-220

L-4B

SP-230

PC-1

ANTENNA SELECTOR

WATTMETER & SENSOR

ST5000

AUTOKEYER

SCOPE SWITCH

RTTY SWITCH

TR9000 & T.T. PAD

ROTATOR CONTROL & ROTATOR

TTY

TTY TX/RX SWITCH

CLOCK